



**Motorbike
Paint**
LTD

SPECIALISTS IN ORIGINAL MOTORBIKE COLOURS

RS Motorbike Paint Limited
Unit 5 Alpha Business Park, Welham Green,
Hertfordshire AL9 7NT
Tel / Fax: 01707 273219
Web: www.rsbikepaint.co.uk
Email: sales@rsbikepaint.co.uk
(VAT Reg. No. 364 1483 53)

Cellulose High Build Primer

Description

A high-build, quick drying and flexible primer. It is not suitable for bare surfaces (metal, plastic or fibreglass.)

Mixing Ratio

Your primer will need to be mixed with cellulose thinner/reducer at a ratio of 50:50 ie 1 part primer to 1 part thinner/reducer. We are unable to supply this due to dangerous goods shipping restrictions, however you should be able to source this locally.

Application

Ensure all surfaces are clean, dust free and have been degreased.

Air cap: 1,4 - 1,6 mm

Apply 2- 3 light coats.

Drying Times

Air drying at 20°C

Allow 10-15 minutes between coats

Thorough drying in 1 hour.

Rub down lightly with 800 sandpaper.