



**Motorbike
Paint**
LTD

SPECIALISTS IN ORIGINAL MOTORBIKE COLOURS

RS Motorbike Paint Limited
Unit 5 Alpha Business Park, Welham Green,
Hertfordshire AL9 7NT
Tel / Fax: 01707 273219
Web: www.rsbikepaint.co.uk
Email: sales@rsbikepaint.co.uk
(VAT Reg. No. 364 1483 53)

Cellulose High Build Primer

Description

A high-build, quick drying and flexible primer. It is not suitable for bare surfaces (metal, plastic or fibreglass.)

Mixing Ratio

Your primer will already have been thinned 50:50 with cellulose thinner, unless you have requested otherwise.

Application

Ensure all surfaces are clean, dust free and have been degreased.

Air cap: 1,4 - 1,6 mm

Apply 2- 3 light coats.

Allow 10-15 minutes between coats

Thorough drying in 1 hour.

Rub down lightly with 800 sandpaper.